



Venturi Jet Junk Basket

1.688 inch

1.813 inch

MAN-TTT-320-1688 (R01)

Thru-Tubing Technology

A Division of Owen Oil Tools LP

402 Machine Loop

Scott, Louisiana, 70583, USA

Phone: +1 (337) 984-1181

Fax: +1 (337) 984-3044

www.corelab.com/owen

Warning: Use of Owen equipment contrary to manufacturer's specifications or operating instructions may result in property damage, serious injury or fatality.

This technology is regulated by and, if exported, was exported from the United States in accordance with the Export Administration Regulations (EAR). Diversion contrary to U.S. law is prohibited. Export and/or re-export of this technology may require issuance of a license by the Bureau of Industry and Security (BIS), U.S. Department of Commerce. Consult the BIS, the EAR, and/or Owen Compliance Services, Inc. to determine licensing requirements for export or re-export of this technology.

This document contains Confidential Information of Owen Oil Tools LP (Owen) and is furnished to the customer for information purposes only. This document must not be reproduced in any way whatsoever, in part or in whole, or distributed outside the customer organization, without first obtaining the express written authorization of Owen. This document is the property of Owen and returnable upon request of Owen.

© 2008 Owen Oil Tools LP

1.688 - 1.813 Venturi
Jet Junk Basket



Description/Operation

The Venturi Jet Junk Basket is used to retrieve junk from the wellbore. When fluid is pumped through the coil tubing to the Venturi, nozzles direct the flow to the OD of the tool toward the bottom, a vacuum is created in the Venturi chamber and fluid and debris is drawn into the bottom of the tool. A debris screen is located between the Venturi chamber and the cages that will hold the debris inside the tool. The cages are used to trap the debris from falling out, and the screen prevents it from recirculating around the ports. The volume of the debris chamber may be enlarged by the addition of extensions between the cage housing and the screen housing. The nozzles are replaceable to achieve any possible ratio of flow rate and psi combination. The Cage Housing on the bottom of the tool can also be dressed with carbide for milling or washing over a fish. The housings are also available with CS threads. An important feature of the Venturi is that it is not dependant on the hole size to work. The rate of the Venturi action is much higher than the pump rate, no matter the hole size and nitrogen can be used without any damaging the tool. The Venturi can be run with or without a mud motor.



Note: Unless otherwise indicated, all the strength figures given in this manual, are the result of calculations based on the yield strength of the material used in the manufacture of this product. These strength calculations are considered accurate within plus or minus 20% and are to be used only as a guide. They do not constitute a guarantee, actual or implied. In use, appropriate allowance should be made as a safety factor.

Flutter Cage - open and closed

These tools only use Flutter Cages, size 1-1/32 in. for the 1.688 and 1-7/32 in. for the 1.813.



1.688 - 1.813 Venturi Jet Junk Basket



Nozzle Flow Chart, Water - 1.688 and 1.813

| Nozzle Number | Nozzle Size (in.) | Capacity in Gallons Per Minute at psi | | | | | | |
|---------------|-------------------|---------------------------------------|---------|---------|---------|-----------|-----------|-----------|
| | | 500 psi | 600 psi | 700 psi | 800 psi | 1,000 psi | 1,500 psi | 2,000 psi |
| 25 | 0.129 | 10.5 | 11.5 | 12.4 | 13.2 | 14.8 | 18.1 | 20.9 |
| 30 | 0.141 | 12.5 | 13.7 | 14.8 | 15.8 | 17.7 | 21.7 | 25 |
| 35 | 0.147 | 13.7 | 15 | 16.2 | 17.3 | 19.4 | 23.7 | 27.4 |
| 40 | 0.156 | 15.4 | 16.9 | 18.2 | 19.5 | 21.8 | 26.7 | 30.8 |
| 50 | 0.172 | 18.7 | 20.5 | 22.2 | 23.7 | 26.5 | 32.4 | 37.4 |
| 60 | 0.188 | 22.3 | 24.4 | 26.4 | 28.2 | 31.5 | 38.6 | 44.6 |
| 70 | 0.196 | 24.3 | 26.7 | 28.8 | 30.8 | 34.4 | 42.2 | 48.7 |
| 80 | 0.203 | 26.1 | 28.6 | 30.9 | 33.1 | 37 | 45.3 | 52.3 |
| 90 | 0.219 | 30.3 | 33.2 | 35.9 | 38.4 | 42.9 | 52.5 | 60.6 |
| 100 | 0.234 | 34.8 | 38.1 | 41.2 | 44 | 49.2 | 60.3 | 69.6 |
| 110 | 0.242 | 37.1 | 40.7 | 43.9 | 46.9 | 52.5 | 64.3 | 74.2 |
| 120 | 0.250 | 39.6 | 43.4 | 46.9 | 50.1 | 56 | 68.6 | 79.2 |
| 130 | 0.272 | 46.9 | 51.4 | 55.5 | 59.3 | 66.3 | 81.2 | 93.8 |
| 140 | 0.281 | 50.1 | 54.9 | 59.3 | 63.4 | 70.9 | 86.8 | 100 |
| 150 | 0.297 | 55.9 | 61.2 | 66.1 | 70.7 | 79 | 96.8 | 112 |
| 160 | 0.302 | 57.8 | 63.3 | 68.4 | 73.1 | 81.7 | 100 | 116 |
| 170 | 0.313 | 61.9 | 67.8 | 73.2 | 78.3 | 87.5 | 107 | 124 |
| 180 | 0.316 | 63.3 | 69.3 | 74.9 | 80 | 89.5 | 110 | 127 |

Note: All the above flow rates & pressures are based on fresh water as a fluid.

| Weight of Solution | Specific Gravity | Conversion Factor |
|-----------------------------|------------------|-------------------|
| 7.0 lbs. per gallon | 0.84 | 1.09 |
| 8.0 lbs. per gallon | 0.96 | 1.02 |
| 8.34 lbs. per gallon -WATER | 1.00 | 1.00 |
| 9.0 lbs. per gallon | 1.08 | 0.96 |
| 10.0 lbs. per gallon | 1.20 | 0.91 |
| 11.0 lbs. per gallon | 1.32 | 0.87 |
| 12.0 lbs per gallon | 1.44 | 0.83 |
| 14.0 lbs. per gallon | 1.68 | 0.77 |

To calculate flow rates for other fluids than fresh water, multiply the tabulated capacities by the conversion factor that applies to the specific gravity of the desired liquid from the chart at the left.

Nozzle capacities vary with different pressures. As a rule of thumb to the relationship between GPM & Pressure is as follows:

$$\frac{GPM_1}{GPM_2} = \frac{\sqrt{psi_1}}{\sqrt{psi_2}}$$

Nozzle Flow Chart, Gas - 1.688 and 1.813

Using a Gas at 80° F with a Specific Gravity Gas of 0.967

| Nozzle Number/Size (in.) | Capacity in Standard Cubic Feet Per Minute at psi | | | | | | | | | | | | | |
|--------------------------------|---|------------|------------|------------|------------|------------|------------|------------|--------------|--------------|--------------|--------------|--------------|--------------|
| | 200 psi | 300 psi | 400 psi | 500 psi | 600 psi | 700 psi | 800 psi | 900 psi | 1,000 psi | 1,100 psi | 1,200 psi | 1,300 psi | 1,400 psi | 1,500 psi |
| 0025/.129 | 47 | 69 | 91 | 113 | 134 | 156 | 178 | 200 | 222 | 244 | 266 | 287 | 309 | 331 |
| 0030/.14 | 56 | 82 | 109 | 135 | 161 | 187 | 213 | 239 | 266 | 292 | 318 | 344 | 370 | 396 |
| 0035/.147 | 62 | 90 | 119 | 147 | 176 | 205 | 233 | 262 | 290 | 319 | 348 | 376 | 405 | 433 |
| 0040/.156 | 69 | 101 | 134 | 166 | 198 | 230 | 263 | 295 | 327 | 359 | 391 | 424 | 456 | 488 |
| 0050/.172 | 84 | 123 | 162 | 201 | 241 | 280 | 319 | 358 | 397 | 436 | 475 | 514 | 553 | 593 |
| 0060/.188 | 100 | 147 | 193 | 240 | 286 | 333 | 379 | 426 | 472 | 519 | 565 | 612 | 659 | 705 |
| 0070/.196 | 109 | 160 | 211 | 262 | 313 | 364 | 414 | 465 | 516 | 567 | 618 | 669 | 720 | 770 |
| 0080/.203 | 117 | 172 | 227 | 281 | 336 | 390 | 445 | 500 | 554 | 609 | 663 | 718 | 773 | 827 |
| 0090/.219 | 136 | 199 | 263 | 326 | 389 | 453 | 516 | 579 | 643 | 706 | 769 | 833 | 896 | 959 |
| 0100/.234 | 156 | 229 | 302 | 375 | 447 | 520 | 593 | 665 | 738 | 811 | 884 | 956 | 1,029 | 1,102 |
| 0110/.242 | 167 | 244 | 322 | 399 | 477 | 554 | 632 | 709 | 787 | 864 | 942 | 1,019 | 1,097 | 1,174 |
| 0120/.250 | 178 | 261 | 343 | 426 | 509 | 592 | 674 | 757 | 840 | 922 | 1,005 | 1,088 | 1,171 | 1,253 |
| 0130/.272 | 211 | 308 | 406 | 504 | 602 | 700 | 798 | 896 | 994 | 1,092 | 1,190 | 1,288 | 1,386 | 1,484 |
| 0140/.281 | 225 | 329 | 434 | 538 | 643 | 747 | 852 | 956 | 1,061 | 1,165 | 1,270 | 1,374 | 1,479 | 1,584 |
| 0150/.297 | 251 | 368 | 485 | 601 | 718 | 835 | 952 | 1,068 | 1,185 | 1,302 | 1,419 | 1,535 | 1,652 | 1,769 |
| 0160/.302 | 260 | 380 | 501 | 622 | 742 | 863 | 984 | 1,105 | 1,225 | 1,346 | 1,467 | 1,588 | 1,708 | 1,829 |
| 0170/.313 | 278 | 407 | 536 | 665 | 795 | 924 | 1,054 | 1,183 | 1,312 | 1,441 | 1,571 | 1,700 | 1,829 | 1,958 |
| 0180/.316 | 282 | 413 | 544 | 675 | 806 | 937 | 1,068 | 1,200 | 1,331 | 1,462 | 1,593 | 1,724 | 1,855 | 1,986 |

Note: The above results are calculated and are not taken from actual test flow rates. Actual flow rates will vary from calculated results. The above calculated results do not constitute a guarantee, actual or implied, as to the flow rate actually

To calculate flow rates for a gas at a different temperature or a different specific gravity gas (S.G.G.), use the following formula to estimate the new standard cubic feet per minute (S.C.F./Min.) rate for the


$$\frac{22.8513 \times (S.C.F./Min.)^*}{\sqrt{S.G.G. \times (Gas Temp. @ ^\circ F. + 460 ^\circ F.)}} = \text{Adjusted S.C.F./Min. for New Temperature/Gas}$$

* Rate from above chart

Nozzle size chart

| Nozzle Number | Nozzle ID | |
|---------------|-----------|-------|
| | (inches) | (mm) |
| 10 | 0.086 | 2.184 |
| 15 | 0.107 | 2.718 |
| 25 | 0.129 | 3.277 |
| 30 | 0.141 | 3.581 |
| 35 | 0.147 | 3.734 |
| 40 | 0.156 | 3.962 |
| 50 | 0.172 | 4.369 |
| 60 | 0.188 | 4.775 |
| 70 | 0.196 | 4.978 |
| 80 | 0.203 | 5.156 |
| 90 | 0.219 | 5.563 |
| 100 | 0.234 | 5.944 |
| 110 | 0.242 | 6.147 |
| 120 | 0.250 | 6.350 |
| 130 | 0.272 | 6.909 |
| 140 | 0.281 | 7.137 |
| 150 | 0.297 | 7.544 |
| 160 | 0.302 | 7.671 |
| 170 | 0.313 | 7.950 |
| 180 | 0.316 | 8.026 |

TT0320-168B BOM, Schematic and Specs



| ITEM | QTY | TOOL PARTS DESCRIPTION | PART NUMBER |
|------|-----|-------------------------|-----------------|
| 1 | 1 | Venturi Section | TT0320-168B-001 |
| 2 | 1 | Screen Sub | TT0320-168A-002 |
| 3 | 1 | Cage Housing | TT0320-168A-003 |
| 4 | 2 | Flutter Cages | TT0321-168A |
| 5 | 1 | Debris Screen | TT0321-168B |
| 6 | 1 | Nozzle (comes in a Kit) | TT0321-168O |

Tool Name: 1.688 in. OD Venturi Jet Junk Basket

Product Code: TT0320-168B **Tool OD:** 1.688 in. **Tool ID:** 1.031 in.

Material: AISI 4140 HT **Tool Length:** 32 in. w/ 1 in. MT Pin

Minimum Yield: 100,000 psi

Strength Properties of Tool:

Minimum Yield Point and Load to Yield: Pin Connection on Venturi Section
PN-TT0320-168B-001, Load to Yield: 67,555 lbs.

Burst Point and Burst Pressure: N/A

Torsional Weak Point and Ft-Lbs to Yield: 1-11/16 in. CWP Connections
Torsional: 688 ft-lbs.


Recommended Make Up Torque:

1st Connection: 1-11/16 in. CWP - 172 ft-lbs.

1.688 - 1.813 Venturi Jet Junk Basket



TT0320-181A BOM, Schematic and Specs



| ITEM | QTY | TOOL PARTS DESCRIPTION | PART NUMBER |
|------|-----|-------------------------|-----------------|
| 1 | 1 | Venturi Section | TT0320-168B-001 |
| 2 | 1 | Screen Sub | TT0320-181A-001 |
| 3 | 1 | Cage Housing | TT0320-181A-002 |
| 4 | 2 | Flutter Cages | TT0321-181A |
| 5 | 1 | Debris Screen | TT0321-168B |
| 6 | 1 | Nozzle (comes in a Kit) | TT0321-168O |

Tool Name: 1.813 in. OD Venturi Jet Junk Basket

Product Code: TT0320-181A **Tool OD:** 1.813 in. **Tool ID:** 1.219 in.

Material: AISI 4140 HT **Tool Length:** 35 in. w/ 1 in. MT Pin

Minimum Yield: 100,000 psi

Strength Properties of Tool:

Minimum Yield Point and Load to Yield: Pin Connection on Venturi Section PN-TT0320-168B-001, Load to Yield: 67,555 lbs.

Burst Point and Burst Pressure: N/A

Torsional Weak Point and Ft-Lbs to Yield: 1-11/16 in. CWP Connections Torsional: 688 ft-lbs; 1-13/16 in. CWP Connections Torsional: 805 ft-lbs.

Recommended Make Up Torque:

1st Connection: 1-11/16 in. CWP - 172 ft-lbs.

2nd Connection: 1-13/16 in. CWP - 201 ft-lbs.

1.0 Pre-Assembly



Warning: *Make sure all tool parts and components have been thoroughly cleaned or serious damage and/or injury could occur!*



Note: *Verify that the correct O-ring redress kit and quantities are used as specified on the Bill Of Materials (for example, 5 each etc....). Lay out all redress kit components on a clean surface.*



Note: *Make sure to lubricate all O-rings and threaded surfaces.*



Note: *Visually inspect all parts for damage or wear. Thread parts together without the O-rings to check fit. Repair or replace damaged parts.*



Caution: *Always file wrench marks or burrs and clean off debris!*



Caution: *This tool should always be disassembled, cleaned thoroughly, inspected and reassembled after each job!*

2.0 Assembly

2.1 Grease the entire ID of the Venturi Section (item #1) and then place into a vise, with the Venturi slot facing up.



Caution: *Do not vise on the Venturi nozzle slot, as it could damage the tool!*

2.2 Grease the entire ID of the Screen Sub (item #2). Insert the Debris Screen (item #5) ring end first, into the Screen Sub. Screw the Screen Sub onto the Venturi Section and make wrench tight.

2.3 If needed, grease and make up the required length of Debris Catchers/Extensions. Standard lengths come in 1-6 ft sections.

2.4 Grease the entire ID of the Cage Housing (item #3). Insert the 2 Flutter Cages (item #4), fingers facing up, into the box end of the housing, then screw it onto the Extensions/Screen Sub wrench tight.

2.5 Put the required Nozzle (item #6), as per the flow chart, into the Venturi nozzle slot and make wrench tight with a 9/16 in. deep socket wrench with an extension.

3.0 Disassembly

3.1 Place the tool in a vise on the Venturi Section (item #1), with the Venturi slot facing up.



Caution: Do not vise on the Venturi nozzle slot, as it could damage the tool!

3.2 Remove the Nozzle (item #6), by using a socket wrench with an extension.

3.3 Move the tool down in the vise to the Screen Sub (item #2).

3.4 Remove the Cage Housing (item #3) and drop, box end first, on a wood block to remove the 2 Flutter Cages (item #4).

3.5 Remove any Debris Catchers/Extensions.

3.6 Remove the Screen Sub (item #2) and drop, box end first, on a wood block to remove the Debris Screen (item #5).



Note: Remove and discard all O-rings. Replace O-rings after each use. Thoroughly clean tool parts in a cleaner approved by state and/or local laws.



Note: Visually inspect tool for swelling after each use. Damaged or swelled components must be replaced.



Note: It is recommended that a Magnetic Particle Inspection (MPI) be completed on all components after each job.